

# WOODSOM Magnetic Holder Installation Instructions

Your new **woodSom** Magnetic Holder has been carefully assembled with neodymium magnets that will securely hold your knives, kitchen tools, jewelry, and other ferromagnetic items you choose to use it for. It has been designed to be securely mounted through the front of the holder to prevent it from pulling away during use.

**Follow these instructions for a level, secure installation of your woodSom product.**

## Required Tools

Level                                      Hammer  
Phillips screwdriver      1/8" drill bit and drill (if installing on wood)

**1. Locate the magnetic holder on the wall and level it in position.** Insert a screw into each mounting hole, then lightly tap to locate position for wall anchors or pilot holes. Set holder aside.



**2. Determine sheetrock or stud installation**  
A) If mounting to wood or a stud, drill a 1/8" pilot in each of the marked locations.  
B) If mounting to sheetrock, screw wall anchors into sheetrock at marked locations until flush. *Note: screws will 'tap' their own threads into zinc wall anchors.*



**3. Install holder with two screws provided.** CAUTION: The woodSom holder has strong magnets that will pull on your screwdriver. Carefully guide the tip of your screwdriver to prevent damage to the wooden face of the holder. **DO NOT OVER-TIGHTEN SCREWS!** This will damage your knife holder.



**4. Gently tap wood plugs into screw holes until flush.**

